
EX260 Series EX600 Series


# **Power Block**

## Power can be supplied individually to 8 power supply systems using up to 4 power blocks.


- Different areas on the same manifold can be controlled by separate-system power supplies.
- Contributes to the reduction of installation space








- Maximum number of outputs: 32 ■ IP67 compliant (Manifold assembly)
- Applicable valves: JSY, SY, VQC, S0700, SV







## EX9-PE1-X15/X22/X23/X24





### **Specifications**

Model		EX9-PE1-X15	EX9-PE1-X22	EX9-PE1-X23	EX9-PE1-X24	
Rated voltage		24 VDC +10 %/-5 %				
Internal current consumption		External power supply 1: 20 mA or less, External power supply 2: 20 mA or less				
Output specifications	Power supply				Outputs 24 to 27: External power supply 1 (PWR1) Outputs 28 to 31: External power supply 2 (PWR2)	
	Output type	Source/PNP (Negative common)				
	Connected load	<ul> <li>Solenoid valve with surge voltage suppressor of 24 VDC and 1.5 W or less (made by SMC)</li> <li>Output block*1</li> </ul>				
	Residual voltage	0.7 VDC or less				
	Rated load current				PWR1 (Outputs 24 to 27): Max. 2 A PWR2 (Outputs 28 to 31): Max. 2 A	
Standards		CE marking				
Enclosure		IP67				
Weight		120 g				
Accessory		Tie-rod 2 pcs.				

<sup>\*1</sup> Refer to the table below.

Model	Note
EX9-OET1	Output block (For low-wattage load), Source/PNP (Negative common), M12 connector
<b>EX9-OEP1</b> *2	Output block (For high-wattage load), Source/PNP (Negative common), M12 connector
EX9-PE1*2	Power block, M12 connector

<sup>\*2</sup> When using the EX9-OEP1, the EX9-PE1 must be connected to the left side of the EX9-OEP1.

#### Plug connector for power supply: M12 pin arrangement A-coded



No.	Function	Description	
1	PWR1 24 V	External power supply 1 24 V	
2	PWR1 0 V*3	External power supply 1 0 V	
3	PWR2 0 V*3	External power supply 2 0 V	
4	PWR2 24 V	External power supply 2 24 V	
5	_	Not used	

 $<sup>*3\,</sup>$  0 V signal lines of No. 2, No. 3, and the power supply for the valve on the SI unit side are internally connected.

#### **How to Order**

EX9-PE1-X15




Symbol	Description
X15	Outputs 0 to 3: External power supply 1 (PWR1), Outputs 4 to 7: External power supply 2 (PWR2)
X22	Outputs 8 to 11: External power supply 1 (PWR1), Outputs 12 to 15: External power supply 2 (PWR2)
X23	Outputs 16 to 19: External power supply 1 (PWR1), Outputs 20 to 23: External power supply 2 (PWR2)
X24	Outputs 24 to 27: External power supply 1 (PWR1), Outputs 28 to 31: External power supply 2 (PWR2)

<sup>\*</sup> Refer to page 1 for combinations.



## EX9-PE1-X15/X22/X23/X24


**Dimensions** [mm]



#### **Accessories**

#### Bracket plate/DIN rail mounting bracket

A reinforcing brace used to mount an output block or power block onto the SI unit of the EX260 series To prevent connection failure between products due to deflection, use this bracket plate whenever an output block or power block is mounted.



## **SMC** Corporation

**SMC CORPORATION** 

Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 FAX: 03-5298-5362 SMC CORPORATION All Rights Reserved

#### **European Marketing Centre (EMC)**

Zuazobidea 14, 01015 Vitoria Tel: +34 945-184 100 Fax: +34 945-184 124 URL http://www.smc.eu